



W. Schmid AG

LED-Technology  
the visible difference

# TS001 Serie

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
A	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
B	A	B	C	D	E	F	G	H	I	J	CH5	CH6	DSK	PIP	C-KEY	CUT	TAKE	REC	ENG	PROD	
C	K	L	M	N	O	P	Q	R	S	T	REPLAY	RET1	RET2	KEY ON	AUTO TAKE	A1	A2	A3	A4	SPK	
D	U	V	W	X	Y	Z	POWER	ON/OFF	ON	OFF	USER A	USER B	USER C	USER D	USER E	USER F	USER G	USER H	USER I		
E	OK	OK	Auto	Enter	Start	STOP	OPEN	CLOSE	Exit	Move	USER J	↺	✕	□	⏪	⏩	⌂	↻	M-1	↻	
F	SET	Reset	Light	Alarm	Menu	Next	Back	Delete	Motor	Save	⏮	↶	↷	↸	↹	✓1	✓2	☰	↑	↻	
G	Up	Down	Right	Left	Test	End	Insert	Lock	Print	+/-	⏮	⏭	⏯	⏰	⏱	⏲	IN PORT	SOS	⚡	TC	
H	ESC	BC.	HOME	Health	D-LED 2	OC GENIE	VIDEO INPUT	clr CMOS	Green Power	Save OK	P1	P2	P3	P4	P5	D C	A C	✉	✉	TURBO	
I	B/R +	Undo/Cancel	T/L -	F1	F2	F3	F4	F5	F6	F7	SEEK	TRACK	RNA	AS/RPT	Select	⏮	SET	ON	OFF	UP	
J	F8	F9	F10	F11	F12	F13	F14	IN 1	IN 2	IN 3	TEST	AUTO	STOP	OPEN	MENU	ON AIR	○	D.	M.	↵	
K	IN 4	IN 5	IN 6	⏻	⏼	⏽	⏾	⏿	⏿	⏿	⏿	⏿	⏿	⏿	⏿	HDMI	VGA	⏻	⏻	⏻	
L	+	-	✕	⏻	⏼	⏽	⏾	⏿	⏿	⏿	⏿	⏿	⏿	⏿	⏿	GAS	PUMP ON/OFF	PURGE	R/HR	PARL	IOD
M	↕	↔	↻	↻	↻	↻	↻	↻	↻	↻	FILL	LO RANGE	MID RANGE	MID	HI RANGE	GPD	EFF LEVEL	⏻	⏻		
N	↑	→	↗	↖	▲	▶	◀	◀	◀	◀											
O	□	⏻	⏼	⏽	⏾	⏿	⏿	⏿	⏿	⏿											
P	⏻	⏻	⏻	⏻	⏻	⏻	⏻	⏻	⏻	⏻											
Q	ME3	ME4	BGND 3D DVE1	BGND 3D DVE2	BUS COLOR	ME BUTTON LINK	*	INSERT	WIPE	⏻											
R	⏮	ALL	⏻	VP	⏻	COPY	⏻	RECORD MODE	↕	✕											
S	⏻	♥	MUTE	⏻	⏻	⏻	⏻	⏻	⏻	⏻											
T	⏻	hold	group	m1	m2	m3	m4	m5	t1	t2											
U	s1	s2	chair	undo	redo	touch	store	recall	e1	e2											
V	e3	e4	OC	⏻	⏻	CLEAR	CROSS WIND	AMMO TEMP	BARO PERSS	AIR TEMP											
W	BORE-SIGHT	CANT	LEAD	RANGE	MRS	ZERO	TEST	UD	LR	⏻											
X	ID	Disp	MF	CALL	.	BAND	SETUP	MODE	LINK	FUNC.											
Y	SHIFT	⏻	⏻	⏻	⏻	DEL	⏻	⏻	⏻	⏻											
Z	⏻	⏻	T	RUN	2D	3D	CH1	CH2	CH3	CH4											